



Tolerance X ± 0.25
 .X ± 0.10
 .XX ± 0.05
 Unless stated otherwise

All information is copyright of allen ©



SEE DETAIL A

DETAIL A
 SCALE 1:1

Spreader Arm 1100mm Red BOM

NUM	QTY	NAME	DESCRIPTION	ACTIONS
1	1	AT-791-1100	Spreader	Ensure end cap is firmly in
2	1	A-625	Spreader end cap	and flush, then screw in 3/8 no.6
3	1	FST6P3-8		



SCALE 1:1

Title	Description	Material	Date	Drawn By
A-791-1100-RED	Spreader Arm 1100mm Red	-	08-Nov-22	B Harris